
## TRANSDUCER ALTER 04CH

## 1. COMPONENT REQUIREMENTS

	TYPE	unit	ST-04CH
1	RATED VOLTAGE	(V)	5.0
2	OPERATING VOLTAGE	(V)	4-6
3	CURRENT CONSUMPTION	(mA)	MAX. 70
4	COIL RESISTANCE	( <u>1</u> 2	30 <u>5</u> +
5	SOUND OUTPUT Distance at 5 cm	(dB)	MIN.100(Typical 103)
6	RESONANCE FREQUENCY	(Hz)	2700
7	OPERATING TEMP.	(°C)	-30 ∼+85
8	STORAGE TEMP.	(°C)	-40 ~ +85
9	WEIGHT	(g)	1
10	TERMINAL		SMD TYPE
11	DIMENSION	mm	L8.5 X W8.5 XH4.0

## 2. TEST CONFIGURATIONS

- Alert Tone Waveform
- The ETACS alert tone will switch between two frequencies in 30 ms for a duration 0.4 sec also in the form of a square wave with a 50% duty cycle.
  - It is off for 0.2 sec before alerting again.
- GSM Alert Tone:Switches between 2 frequencies in 32 ms increments for 1 second.
  - Then the signal is off for 4 sec. after which the cycle repeats. The frequencies are square waves each with a 50% duty cycle.



## 3.TEST FIXTURE

